


## BCR STARLINK

Starlink states that it can take up to 24 hours to reach full speed as the Starlink is still figuring out where it is and whether or not it has a clear view of the sky.

### Step 1.

Plug the long cable into the Starlink, and put the Starlink on its base. Please beware that it only fits one way. Plug the other end of the cable into the ethernet adapter, plug the ethernet adapter into the router and plug the power cable in the router and the wall.



### Step 2.

Place the Starlink outdoors with a clear view of the sky.

Download the Starlink app and use your phone to connect to the BCR Starlink Wifi network.

The wifipassword is: **1216BP81**

### Step 3.

In the Starlink app, go to settings, Starlink and slide to undock the Starlink. The dish will now start moving. Within a few minutes there should be an internet connection. It can take up to 24 hours to reach full speed as the Starlink is still figuring out where it is and whether or not it has a clear view of the sky

### Before packing

To take the Starlink down you have to dock the Starlink in order for it to fit in its case. In the app, go to settings, Starlink, and slide to dock the Starlink. Now wait for the dish to stop moving before removing power from the router.



Broadcast Rental BV, Nieuwe Havenweg 81  
1216 BP, Hilversum, The Netherlands  
Phone: +31358886825  
Mail : [hire@broadcastrental.com](mailto:hire@broadcastrental.com)



BIC Code : INGBNL2A  
IBAN : NL12INGB0007249487  
VAT : NL821127640B01  
Trade : 32157161